


Corner Steadies and Jackstands

Data Sheet Issue 00/01



APPLICATION

Corner Steadies

Wind down corner steadies can be used on caravans, site huts, portable accommodation and other similar applications for periods of static use. Whilst corner steadies are double braced for side stability and therefore provide a secure footing when supporting or setting up a caravan, they should be used for levelling and supporting the trailer/caravan when stored away. Corner steadies should not be used as a lifting device when e.g. a wheel is changed.

Peak corner steadies are operated by the corner steady brace provided.

Sliding Jackstands

Sliding jackstands provide an economic method of steadying and supporting the trailers structure during loading and unloading or when disconnected from the towing vehicle. To achieve maximum load capacities all jackstands should be mounted vertically, usually at the back, where the destabilising force is experienced most.

Peak sliding jackstands are adjustable for height by means of a clamp bracket through which the stand slides.

Put Peak into Practice

Peak Trailers Limited

Waterloo Industrial Estate, Waterloo Road, Bidford-on-Avon, Warwickshire, B50 4JH
Telephone: 01789 778041 Facsimile: 01789 490331 IDD: 44 789
e-mail: sales@peaktrailers.com Website: www.peaktrailers.com

